



## Color Armor™ Installation Snow Guard Cover

[www.snoshield.com](http://www.snoshield.com)

Note: These installation instructions are provided as assistance to installers. Sno Shield Inc takes NO responsibility for errors in application or omissions and cannot be held responsible for product installation.

Sno Shield Inc warrants the products themselves, not the installation. See Warranty Information.

1. Ensure snow guard is properly attached to roof before applying Color Armor™ if used with the Rib Guard or the mechanically fastened Panel Guard
2. Ensure correct style of Color Armor™ is being used. Color Armor™ for the Rib Guard is notched at one end to allow clearance for the roof panel seam (rib)
3. Align holes on the Color Armor™ with the “pegs” on the base of the snow guard and gently apply pressure to one side then the opposite until the Color Armor™ slides (snaps) onto the snow guard
4. Pull gently on Color Armor™ to ensure proper attachment. If attached properly, Color Armor™ will not come off

**Important: When using the Rib Guard or the mechanically fastened Panel Guard, Color Armor™ must be installed after the snow guard is attached to the roof. If attaching the Panel Guard with adhesive or double-sided tape, Color Armor™ can be installed on the snow guard prior to attachment to the roof. Please note that Color Armor™ has been designed as a permanent fixture, so once applied it is difficult remove.**

Contact Sno Shield Inc for recommended snow guard placement and spacing layouts  
1-888-976-6744      [info@snoshield.com](mailto:info@snoshield.com)      208-524-7371  
3968 E Sunnyside Rd, Bldg 3, Ammon, ID. 83406  
[www.snoshield.com](http://www.snoshield.com)